



# How to clean your Panasonic SA-HT810V VCR heads

Written By: Nathan Cheadle



## INTRODUCTION

This is a guide overview how to clean your VCR heads in your Panasonic DVD/VCR player.

---



### TOOLS:

- [64 Bit Driver Kit](#) (1)
-

## Step 1 — How to clean your Panasonic SA-HT810V VCR heads



- With the front display of the device facing you, rotate the device 90 degrees counter clockwise.
- Remove the screw that is on the right side of the panel facing you.
- Now rotate the device 180 degrees and remove the second screw.
  - Remove all screws with a phillips head screwdriver.

## Step 2



- Rotate the device so that the back faces you.
- With a phillips head screwdriver, locate and remove the 12 screws highlighted by the red circles in image one.





## Step 3



- Before removing cover make sure that the back of the device is facing you.
- Remove the top cover by bending out on the sides, and pulling the cover towards you while applying upward pressure.

## Step 4



- Before cleaning the VCR heads, be sure that the front of the device is facing you with the top cover removed.
- Locate the two VCR heads highlighted in by the blue boxes in image one.
- ⚠ GENTLY clean heads with a microfiber rag and a cleaning solution of your choice.

To reassemble your device, follow these instructions in reverse order.

